

GET READY TO REINVENT YOUR DÉCOR!

PREPASTED WALLPAPER



WALL PREPARATION

It is important to apply your wallpaper to a wall that was painted at least 30 days ago with a gloss or semi-gloss paint. Do not install the panels over plaster or primer.

If you cannot wait 30 days, you can apply **Zinsser Shieldz** clear wall size.



MATERIALS REQUIRED

Clean cloth, water tray, exacto knife, level, measuring tape, sponge for smoothing (do not use plastic), cutting guide (metal square or ruler)



INSTALLATION GUIDE

For all the details on how to install your wallpaper, you can refer to our installation guides on our website at the following address: www.stationd.ca/pages/installation.

You will also find a video on how to install our prepasted wallpaper.

REMOVABLE SELF-ADHESIVE WALLPAPER



WALL PREPARATION

It is important to apply your wallpaper to a wall that was painted at least 30 days ago with a gloss or semi-gloss paint. Do not install the panels over plaster or primer.

If you cannot wait 30 days, you can apply **Zinsser Shieldz** clear wall size.



MATERIALS REQUIRED

Clean cloth, exacto knife, level, measuring tape, rubber scraper (provided), cutting guide (metal square or ruler)



INSTALLATION GUIDE

For all the details on how to install your wallpaper, you can refer to our installation guides on our website at the following address: www.stationd.ca/pages/installation.
